




Acer Aspire V5-572, V5-572G Wi-Fi half mini PCIe card Replacement

Acer Aspire V5-572, V5-572G Wi-Fi half mini PCIe card Replacement

Written By: ZFix



INTRODUCTION

Acer Aspire - V5-572, V5-572G

How to disassemble the Laptop and replace the Wi-Fi Card.

[Please SUBSCRIBE to my channel ツ](#)


[video: <http://youtu.be/Sg8tUXZL864>]



TOOLS:


- [Phillips #0 Screwdriver](#) (1)
 - [iFixit Opening Tools](#) (1)
 - [iFixit Opening Picks set of 6](#) (1)
-

Step 1 — Bottom Cover




- Switch-off the Laptop.
- Remove 17x Philips screws.

Step 2



- Start opening from the SD Memory Card hole
- ⚠ Use plastic tools to avoid damaging the cover.




Step 3



⚠ Before doing anything, disconnect the battery.

★ [Please SUBSCRIBE to my channel](#) ツ

Step 4 — Wi-Fi half mini PCIe card



- Remove 1x screw and disconnect the two antenna coaxial cables.
- Remove the Wi-Fi card from the slot.

★ [Please SUBSCRIBE to my channel](#) ツ

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 07:56:37 AM.